




FUNDAMENTAL FREQUENCIES OF SELECTED MUSICAL INSTRUMENTS



Audio cables without networks resist all frequencies below 1500-2500 Hz, distorting and fundamentally altering the sounds of all musical instruments.



CABLE WITHOUT NETWORK ALTERS MUSICAL CHARACTER



TRANSPARENT CABLE KEEPS YOU CLOSEST TO THE MUSIC

